

POLY-CAP INSTALLER



DIRECTIONS FOR USE

In order to install the Poly-Cap properly, you will need 3 people. Have one person on each side of the fence holding the Installer and a third person in front holding the Poly-Cap up to the top of the fence in place so you can move forward rapidly. Note before you begin, unroll the Poly-Cap next to the fence to avoid delays once you get started.

Insert the circular area of the Installer into the slit of the Poly-Cap near one end and turn the Installer 90 degrees. This will spread the Poly-Cap wide enough to allow you to place the Installer and Poly-Cap over the top of the chain link and top rail.

When you start the installation process allow an extra 1-2 feet of Poly-Cap to extend beyond the end of the fence and secure the Poly-Cap to the fence with Poly-Cap Ties as soon as you have a start. Do this to prevent the Poly-Cap from being pulled forward at first, which can cause you to have a gap on the beginning of your fence line. Trim any excess Poly-Cap when you are finished.

As you move forward keep one hand on top of the Poly-Cap just behind the Installer and push down lightly. This will make sure the Poly-Cap closes around the fence and top rail.

When you have finished your installation run, walk your fence line and push the Poly-Cap down securely where needed and install the optional Poly-Cap ties every 3-5 feet. This will keep the Poly-Cap secured to the fence and give it a nice level appearance.

Note: on older fences where the chain link fabric has pulled away from the top rail, installation can be more difficult. The chain link fabric can snag the Poly-Cap as you move forward. To reduce this problem, simply push one side Installer against the “clean” side of the fence. This will allow a larger opening on the other side to “envelop” the chain link fabric. If you still have areas that “snag” the Poly-Cap as you move forward, stop and use your fingers to put the chain link inside the Poly-Cap then continue forward.